

VK-55SE

WARRANTY REGISTRATION FORM

| Unit Serial Number: | |
|---------------------|--|
| Customer Name: | |
| Address: | |
| | |
| Date of Purchase: | |
| D 1 15 | |
| Purchased From: | |
| Dealer Name: | |
| Address: | |
| | |

IMPORTANT NOTE:

In order to receive the full five year product warranty, please mail this completed form together with a copy of your sales receipt to Balanced Audio Technology at the address below, within **thirty days** of purchase.

Failure to do so will result in the product being warrantied for **one year** from the date of manufacture.





VK-55SE Balanced Power Amplifier

Owner's Manual

Introduction

Thank you for your purchase of the Balanced Audio Technology VK-55SE power amplifier. Please read this owner's manual to obtain the full benefit of the VK-55SE in your system. This manual provides you with necessary safety information and operating procedures for this exceptional unit.

WARNINGS:

To prevent the possibility of serious injury, electrical shock, or fire:

DO NOT operate with the bottom cover removed.

DO NOT expose to rain or moisture.

DO NOT defeat the ground power-plug.

DO NOT replace fuses with anything other than the same type and rating as supplied by the factory.

Package Contents

Included in the box should be the following:

| VK-55SE Power Amplifier 1 | |
|---------------------------|--|
| 6C33C-B Output Tubes 4 | |
| 6SN7 Signal Tubes 2 | |
| 6H30 Signal Tubes 2 | |
| Power Cord 1 | |
| Torx Wrench (T-10) | |
| Spare Cover Screws 5 | |
| Spare Fuses 3 | |
| Owner's Manual 1 | |

Save all the packaging materials in a safe dry area for the unlikely event that you need to return the VK-55SE to the factory for service.

Installing Tubes

Install the signal 6SN7 and6H30 tubes can in the front sockets. When installing the output 6C33C-B tubes please make sure their pins are lined up with the sockets. Insert the tubes with gentle downward pressure, while making slight rocking motion to fascilitate the proper insertion.

The two 6922 tubes used as gain stage current sources, are located inside the chassis. To gain access to them, remove the bottom cover. The unit is shipped to you with these tubes installe.

Physical Placement

It is recommended that you provide open space above the unit for proper ventilation, with no electronic components placed directly overhead.

Mount the unit on a hard surface with proper ventilation underneath. Avoid placing the unit directly on a carpeted floor.

Connecting the VK-55SE to Your System

For Balanced Preamplifiers:

Use balanced XLR interconnects. The left and right channel input connectors are clearly marked on the back panel of the VK-55SE.

Note: The VK-55SE XLR inputs are wired as follows:

Pin 1: common/ground

Pin 2: positive Pin 3: negative

For Single-Ended Preamplifiers:

Single-ended preamplifiers have RCA connectors. The VK-55SE power amplifier is designed to work with either balanced or single-ended preamplifiers connected to its inputs. All that is required to connect a single-ended preamplifier with RCA connectors to the VK-55SE's inputs is the optional balanced to single-ended adapters. These adapters are available from Balanced Audio Technology at a nominal charge.

For Speaker Connections:

The speaker connectors are clearly marked on the back panel of the VK-55SE. There are several sets of output taps marked LOW, MEDIUM and HIGH for connecting a variety of speakers to the VK-55SE. Please note that some experimentation may be required. Try each output tap until you find the one that gives the most balanced performance in your system.

Operating the VK-55SE

Normal operation of the VK-55SE requires simply turning the unit on. There are no meters to connect, bias setpoints to remember, or drifting bias points to adjust. Please read the **Autobias Feature** section for more details.

Turning the VK-55SE On:

The power switch is located at the front of the unit. As tubes warm up, their green LED bias indicators will turn ON indicating their readiness. Different tubes can take different times to get ready, but normally all four LED's should be ON after about one minute. Conditions such as low line voltage and tubes' age can delay the readiness of the tubes.

Turning the VK-55SE Off:

The unit can be turned Off at any time (even while playing). If needed, please wait at least 30 seconds before turning the unit ON again.

Autobias Feature:

The VK-55SE implements a sophisticated autobias circuit that automatically compensates for tube aging and line voltage fluctuations, as well as marginal mismatching of tubes. The successful operation of the autobias circuit is noted by individual LED's that glow visibly next to each output tube when viewed from the top of the chassis. A total of four LED's should light up to indicate proper operation of the circuit. If one of the LED's fails to light up (after the unit is warm), there could be two reasons for this problem:

- 1. The particular output tube is defective. In this case replacing this tube with a known good one should turn the LED ON.
- 2. The amplifier was overstressed and the protective fuse inside opened. These fuses protect output tubes from overloading. There are two fuses accesible through the top of the unit. Please refer to the section on replacing fuses for correct ratings.

Replacing Fuses:

WARNING: Please turn the unit OFF and disconnect the power cord before proceeding.

There are three fuses in the VK-55SE. The main Slow-Blow fuse (10A rating for 110-120VAC line voltage and 5A for the 200-240VAC range) is located on the unit's back panel.

The two **3A Fast**-Acting protection fuses are mounted on the VK-55SE printed circuit board and can be acsessed through the holes in the amplifier top plate.

If the pilot LED on the front panel goes out, try replacing the main fuse on the back panel with the same type fuse.

If one or more of the autobias LED's has gone out, turn the unit off and wait for few minutes before proceeding, allowing the internal electrical charge to Remove and replace the blown fuse with the 3A Fast-Acting type.

In either case, if the unit still fails to operate properly, please contact the factory for professional service.

Factory supplied fuses should only be replaced with the same type and rating parts.

Replacing Output Tubes:

To maintain the optimal performance of your unit, replace the 6C33C-B output tubes only with matched sets available from Balanced Audio Technology. If only one tube fails, then just one pair needs to be replaced.

Please do not substitute any random tube as a replacement. Although the automatic bias circuit in the VK-55SE will accept virtually any random set of output tubes, the unit will not be guaranteed to meet all of its performance specifications under such conditions. Finally, the determination that a **single tube replacement** is prudent rests solely with the customer, based on actual hours of use for the particular set of tubes. The factory assumes no responsibility for possible performance decrease under such conditions

Servicing:

The Balanced Audio Technology VK-55SE should require no service other than tube replacement to maintain its high performance. Please direct any further service inquiries to the factory.

Cleaning:

To remove dust, occasionally wipe the front and top surfaces of your VK-55SE with a damp soft cloth. If fingerprints appear, you may use a mild, non-alkaline soap solution. Do not use abrasive cleaners, as they may damage the fine finish of the unit.

VK-55SE Limited Warranty

Terms and Conditions

1. Limited Warranty

Upon receipt of the attached warranty registration form, Balanced Audio Technology warrants the purchased product to be free from manufacturing, materials, and workmanship defects for **five years** from date of original purchase, excepting vacuum tubes, subject to the following conditions. **Failure to return the enclosed warranty registration form together with a copy of your sales receipt within 30 days from original purchase will result in a warranty period of one year from the date of manufacture.**

2. Vacuum Tubes

The 6SN7 and 6H30 vacuum tubes (including replacements under warranty) are warrantied for one year from the date of the original VK-55SE purchase. The output 6C33C-B vacuum tubes are warrantied for ninety days.

3. Limited to Original Purchaser

This warranty is for the sole benefit of the original purchaser of the covered product, and may not be transferred to a subsequent purchaser of the product.

4. Conditions and Limitations

This warranty is subject to certain conditions and limitations, as follows. This warranty is void and inapplicable if the product has not been used in accordance with the instructions found elsewhere in this manual, or if it has been misused or abused, damaged by accident or neglect, or in transport once in possession of the purchaser. The warranty is also void if the product has been repaired, modified, or tampered with by anyone other than Balanced Audio Technology or its specifically authorized agents.

5. Remedy

If this product contains a materials, manufacturing, or workmanship defect that cannot be repaired at the dealership where the product was purchased, it must be packed in original packaging and returned to Balanced Audio Technology via insured freight, at the owners expense. If replacement packaging materials are required, they will be supplied by the factory at a nominal charge. **Returned products must be accompanied by a written description of the defect, and a return authorization number (available from the factory via phone or fax).** Upon receipt of defective product, Balanced Audio Technology agrees to repair the product without charge for parts (except vacuum tubes if the unit is more than one year old), or labor. The product will then be returned via prepaid, insured freight, with carrier at the sole determination of Balanced Audio Technology. This constitutes the purchasers sole remedy.

6. Design Changes

Balanced Audio Technology reserves the right to modify its products or change specifications at any time without obligation or liability to previous purchasers.

7. Miscellaneous

Any implied warranties relating to the above product shall be limited to the duration of this warranty. This warranty does not extend to any incidental or consequential costs or damages to the purchaser. This warranty gives you specific legal rights. You may also have other rights which vary from state to state.